How To: Family Room 3rd Floor TV

The Family Room TV does not need Wi-Fi to function, although it may ask you to join “MyConnect”. Below are picture steps on how to back out of the Wi-Fi screen and get to watching cable television. Follow the red rectangles on the images and the red circles on the remote.

Thank you!






Connect to Your Network
MERCYMEDEQUIP
Signal strength: Good
MYCONNECT
Signal strength: Good
WIFI@MERCY
Signal strength: Good
Join Other Network
Press to do this later.


Are you sure?
An internet connection is necessary to access content such as streaming movies, TV shows, and apps. If you quit setup now, this content will not be available.
Skip Wi-Fi setup
Connect to Wi-Fi


Create or Sign In to your Amazon account
Your Amazon account gives you access to thousands of channels, movies and TV shows, and apps.
Learn More
fire tv
Home
Inputs
Notifications
Amazon Account Sign in/up
Network
Display & Sounds


Home
Inputs
Notifications
Amazon Account Sign In/up
Network
Display & Sounds
Equipment Control
Live TV
Controllers & Bluetooth Devices
Preferences
Sleep Timer
Device & Software
Accessibility
Help


Inputs
INPUTS
Antenna
HDMI1
HDMI2
HDMI3
HDMI4
Switch input with Voice
Switch Input with Voice.
Learn More
NETFLIX
hulu
fire tv